

- 1 Fläche gründlich von Fett-, Staub- und Schmutzrückständen reinigen.

A) Echt-Alu Blende: Durch Biegen der zu beklebenden Form anpassen. Bei ausgeschnittenen Heckstoßstangen Rundung auf einer Papierschablone markieren und auf Blende übertragen. Rundung mit Bleischere ausschneiden.

B) Alu-Look Folie auf gewünschte Größe zuschneiden.

- 2 Schutzfolie abziehen und CUPROHR-Blende aufkleben.
- 3 Vom Rand ausgehend mit beiliegendem Raketel bzw. weichem Tuch blasenfrei andrücken.
- 4 ...und fertig ist der RENN-Look!

- 1 Clean the surface thoroughly to remove oil, dust and dirt residues.

A) Heat shield: bend to fit the shape of the area to be covered. In the case of cut-out rear bumpers, mark the cut-out on a paper template and transfer to the trim. Cut out with sheet shears.

B) Cut DesignFilm to required size.

- 2 Remove the protective film and apply the Pipe DesignTrim.
- 3 Using the squeegee (included) or a soft cloth, work the air bubbles out from the edge.
- 4 ...and that's all it takes exiting Race-Look!

C U P
R O H R
B L E N D E

FOLIATEC.com

MONAGEANLEITUNG • INSTALLATION INSTRUCTION

P I P E
DESIGNTRIM

FOLIATEC Böhm GmbH & Co Vertriebs KG
Neumeyerstr. 70, 90411 Nürnberg, Germany
Tel.: +49(0)911/97544-0
Fax: +49(0)911/97544-333
techsupport@foliatec.de
www.foliatec.com